



WARNING:

This list indicates which Lotus LED fixtures have a suitable Wattage requirements in relation to the listed Emergency Drivers. Each such installation may require additional hardware (such as J-Boxes) in order to hold the wire connections necessary to complete the install according to code requirements.

Additionally, each emergency driver has a Test Button and Indication lights, which need to be visible and installed to code requirements. It is recommended to prewire and install all the emergency drivers prior to closing the ceiling.

Lotus LED Lights Model	Compatible Emergency Driver Model
LL3G, LRG3, LSG3	ACE-G4L-55-73, ILB-CP05-A
LY4RCS	ACE-G10-55-190C, ACE-G4L-55-73, ILB-CP05-A
LD4R, LD4S, LL4G, LRG4, LL4R, LL4RR, LL4SR, LL4S, LY41RCD, LB4R, LY4S, LY6RCS, LL6R, LB6R, LY61RCD, LY6S, LB8R	ACE-G10-55-190C, ACE-G4L-55-73, ILB-CP07-A, ILB-CP05-A
LD6R, LRG6, LL6RR, LL6SR, LD8R, LY82RCD, LL8R, LL10R	ACE-G10-55-190C, ACE-G4L-55-73, ACE-H20-55-380C, ILB-CP07-A, ILB-CP05-A, ILB-CP10-A