

**RB4****Remote control for SP630E****DESCRIPTION**Remote control for universal controller [SP630E](#)

2.4 GHz with long transmission distance

One remote can control multiple controllers

One controller can pair with up to 5 remotes

INSTRUCTIONS**1 ON**

Short press: Turn on the light.

Long press: Within 20s after the controller is powered on, long press **ON** to bind/unbind the remote control.**2 OFF**

Short press: Turn off the light.

Long press: Within 20s after the controller is powered on, first turn off the lights completely, and then long press the **OFF** button to clear all bound remote controls.**3 ZONE**Short press: select specific zone, E.g: short press **1** first, then press **MODE+**, then only zone 1 will respond to this operation.Long press: zone setting, within 20s after the controller is powered on, long press a key **1**...**4** to set the controller to specific zone.**4 ALL**

Short press: select all zones.

long press: Within 20s after the controller is powered on, long press **ALL** to unset the zones.**5 MODE+****6 MODE-****7 SPEED****8 MUSIC MODE****SPECIFICATION**

Battery	3V CR 2032
Range	100 ft / 30 m
RF Frequency / WiFi	2.4 GHz
Dimensions	5 3/8" x 1 7/8" x 7/16" (135 x 48 x 10 mm)
Operating Temperature	-4°F (-20°C) to +140°F (+60°C)
IP Rating	IP20
Certification	CE, FCC
Warranty	3 Year

ORDERING GUIDE**RB4****Lotus LED Lights USA**

250 H Street # 301, Blaine WA 98230 tel 360-200-5500

Hainesport NJ & Ferndale WA

www.LotusLEDLights.com

mailing addresses

warehouses

Lotus LED Lights CANADA

1080 Cliveden Ave # 6, Delta BC V3M 6G6 tel 604-538-3090

Delta BC & Mississauga ON